




# 80 Series 4 Post Brake Instructions

Read carefully before attempting to assemble, install, operate or maintain the product described. Protect yourself and others by observing all safety information. Failure to comply with instructions could result in personal injury and/or property damage! Retain instructions for future reference. When unpacking the brake, inspect it carefully for damage that may have occurred during transit.



Standard Housing

Enclosed Housing

Figure 1.

## WARNING

Brake performance and features must be carefully matched to the requirements of the application.

Consideration must be given to torque requirements, especially where an overhauling condition exists, as well as thermal capacity, ambient temperature, atmospheric explosion hazards, type of enclosure and any other unusual conditions.

Improper selection and installation of a brake and/or lack of maintenance may cause brake failure which could result in damage to property and/or injury to personnel.

If injury to personnel could be caused by brake failure, additional means must be provided to insure safety of personnel.

Do not operate manual release or energize brake coil before installation, in order to preserve prealignment of rotating discs for ease of installation.

## DESCRIPTION

This brake is direct acting, electromagnetically released and spring set. It uses rotating and stationary disc contact to supply positive braking action. It retains quick release and setting capabilities at all times.

Simplicity of design has reduced maintenance to an absolute minimum. As with any electromechanical equipment, however, periodic inspection and adjustment will assure optimum performance. As the friction disc wears, the magnet gap will increase. The magnet gap should be checked periodically and adjusted when necessary.

## INSTALLATION

(See Figures 3, 5 & 6, Tables 1, 2 & 3)

1. Remove hub (1) from brake and position on motor shaft with key according to dimension "N". Stamped part number on hub should face away from motor. Tighten hub set screws with 12 lb. ft. torque.
2. Remove cover screws (24) and cover (23), plus gasket (28) on enclosed and severe duty models.
3. Place brake on motor, guiding discs on hub.
4. Bolt brake to motor "C" face with four 1/2 inch socket head cap screws. See Figures 5 and 6 for screw length thru bracket.
5. Connect coil leads per appropriate wiring diagram in Figure 2 and replace cover.




Figure 2. Wiring Diagram



Table 1. Parts List

ITEM NO.	PCS. REQ'D	DESCRIPTION	2-80000-29 SERIES PART NO.	4-80000-29 SERIES PART NO.	6-80000-32 SERIES PART NO.
1	1	Hub			
2	1	Bracket W/Studs – 1 Disc	H080105-001		
2	1	Bracket W/Studs – 2 Disc	H080105-002		
2	1	Bracket W/Studs – 3 Disc	H080105-003		
2	1	Bracket W/Studs – 4 Disc	H080105-004		
2	1	Bracket W/Studs – 5 Disc	H080105-005		
2a	1	Bracket W/High Tensile Studs – 1 Disc	H080105-006		
2a	1	Bracket W/High Tensile Studs – 2 Disc	H080105-007		
2a	1	Bracket W/High Tensile Studs – 3 Disc	H080105-008		
2a	1	Bracket W/High Tensile Studs – 4 Disc	H080105-009		
2a	1	Bracket W/High Tensile Studs – 5 Disc	H080105-010		
3	4	Stud – 1 Disc		G070213-001	
3	4	Stud – 2 Disc		G070213-002	
3	4	Stud – 3 Disc		G070213-003	
3	4	Stud – 4 Disc		G070213-004	
3	4	Stud – 5 Disc		G070213-005	
3a	4	Stud – 1 Disc High Tensile		G070219-001	
3a	4	Stud – 2 Disc High Tensile		G070219-002	
3a	4	Stud – 3 Disc High Tensile		G070219-003	
3a	4	Stud – 4 Disc High Tensile		G070219-004	
3a	4	Stud – 5 Disc High Tensile		G070219-005	
4	(1)	Rotating Friction Disc		H080002-002	
4a	(1)	Heavy Duty Rotating Friction Disc (Alt.)		H080026-003	
5	(2)	Stationary Disc		K080179-001	
6	1	Pressure Plate		K080072-001	
7	4	Torque Spring (25, 50, 75 Lb. Ft.)		G070011-001	
7	4	Torque Spring (35, 70,105,125,175 Lb. Ft.)		G070019-001	
8	4	Torque Spring Washer		W004004-001	
9	4	Torque Adjusting Nut		W003001-022	
10	2	Manual Release Rod		G070001-002	
11	2	Manual Release Spring		G060010-001	
12	2	Manual Release Washer		W004004-003	
13	As Req'd	Manual Release Shim		W004004-004	
14	2	Manual Release Stop Screw		G060029-001	
15	2	Manual Release Lockwasher		W004007-007	
16	1	Magnet Assembly, Single Phase – Complete with Coils		K080126 (3)	
16	1	Magnet Assembly, Three Phase – Complete with Coils		K080127 (3)	
17	1	Magnet Plate w/o Coils, Single Phase		K080152-001	
17a	1	Magnet Plate w/o Coils, Three Phase		K080101-001	
18	4	Magnet Coil – Single Phase		K080083 (3)	
18a	6	Magnet Coil – Three Phase		H080062 (3)	
19	2	Insulating Washer – Single Phase		G080148-001	
19a	2	Insulating Washer – Three Phase		G080016-001	
20	2	Shading Coil, Single Phase Only		G080022-001	
21	4	Gap Adjusting Nut		W003003-023	
22	4	Gap Adjusting Nut		W003001-020	
23	1	Cover, Standard	L080067-001	L080056-002	
23	1	Cover, w/ Thru Shaft	L080067 (4)	L080056-003	
24	6	Cover Screw		W001013-028A	
25	1	Conduit Hole Plug	W008003-001	W010002-004	
26	1	Name Plate		H050020-001	
27	1	Hub Seal	---	W011001-008	---
28	1	Cover Gasket	---	K080143-001	
29	2	Release Cap	---	G060170-002	
30	1	Thru-Shaft Sleeve	---	H080036 (5)	
31	1	Thru-Shaft Seal	---	W011001-007	
32	6	Lockwasher, 1/4	W004007-009	W004006-006	W004007-009
33	1	Drain Hole Plug	---	W010002-001	
34	2	Release Cap Gasket	---	G070381-001	
35	2	Drive Screw		W001012-048	

(1) Number of rotating discs is shown as second digit of Model No.  
Example: 2-82050-28

(2) Number of stationary discs is one less than the number of rotating discs.

(3) Basic part number shown – specify model number, voltage, phase and frequency.

(4) Basic part number shown – specify shaft diameter.

(5) Basic part number shown – specify shaft diameter and keyway.

Table 2. Standard Housing

MODEL NO.	TORQUE LB. FT.	WEIGHT LBS.	THERMAL CAPACITY HPS/MIN	INERTIA WK <sup>2</sup> LB. FT. <sup>2</sup>	DIMENSIONS						
					C	D		H	N ±1/32	AC	X
						MAX	MIN				
2-81025-28	25	65	15	.095	6.31	.065	.035	1.31	1.75	1.50	1.00
2-81035-28	35	65	15	.095	6.31	.065	.035	1.31	1.75	1.50	1.00
2-82050-28	50	71	17	.169	6.94	.065	.035	1.31	2.25	2.12	1.50
2-82070-28	70	71	17	.169	6.94	.065	.035	1.31	2.25	2.12	1.50
2-83075-28	75	77	19	.244	7.56	.070	.040	1.31	2.75	2.75	2.00
2-83105-28	105	77	19	.244	7.56	.070	.040	1.31	2.75	2.75	2.00
2-84125-28	125	83	21	.318	8.19	.080	.050	1.43	3.25	3.38	2.50
2-85175-28	175	89	21	.395	8.81	.080	.050	1.31	3.87	4.00	3.12




Figure 5. Standard Housing



## TROUBLE SHOOTING

### A. IF BRAKE DOES NOT RELEASE:

1. Check brake visually for broken or damaged parts.
2. Check for broken leadwire or bad electrical connection.
3. Check for correct voltage. Line voltage must correspond to the voltage for which the brake coils are connected. If the line voltage is more than 10% below the voltage for which the brake coils are connected, the magnet will not pull in, causing the coils to burn out within minutes. If the line voltage is more than 10% above the voltage for which the brake coils are connected, the coils will overheat and burn out.
4. Check for burned-out coils (coils may be charred or burned).
5. Check for excessive magnet gap. (See WEAR ADJUSTMENT.)
6. Check for failure or power supply to brake.

### B. IF BRAKE DOES NOT STOP:

1. Check brake visually for broken or damaged parts.
2. Make certain hub has not shifted position on the motor shaft and that all rotating discs are fully engaged on the hub.
3. Check that the manual release is in the normal position.
4. Check disc wear. (See WEAR ADJUSTMENT.)

### C. IF BRAKE CHATTERS OR HUMS:

1. See that magnet faces are clean. To remove dirt, insert a clean sheet of paper between magnet faces and energize brake. Move paper around between faces to dislodge dirt, then remove paper.
2. Check for low voltage. Magnet will not pull in, and coils will burn out if line voltage is beyond 10% below the voltage the brake coils are connected for.
3. See that magnet faces are parallel within tolerance. Readjust magnet gap to "D" min. (See WEAR ADJUSTMENT.)
4. Check if shading coil (20) is cracked, broken or out of position (single phase only).

### D. IF MANUAL RELEASE DOES NOT WORK:

1. Check for broken or damaged parts.
2. Check return spring (11). Brake will not reset automatically if this spring is broken.
3. Check quantity of shim washers (13) under release stop screws. (See MANUAL RELEASE ASSEMBLY.)

## SPECIFICATIONS

**MOTOR FRAMES** - 284TC, 286TC.

**HOUSINGS** - Standard is cast iron and aluminum. Enclosed is all cast iron.

**DUTY** - Rated for continuous duty.

**VOLTAGES** - All standard NEMA voltages and frequencies available. Other voltages and frequencies are optional.

**MOUNTING** - Direct to NEMA "C" motor flanges. Adaptors for larger or smaller frames, foot mounting and vertical mounting are available.

**SHAFTS** - NEMA standard length motor shafts and thru shafts may be used on all models except units with Mark II Release (Cover modification required for thru shafts).

## ORDERING INFORMATION

The following data should be furnished with your order for:

### REPLACEMENT PARTS

Brake Model Number

Part Number from Tables

Part Description from Tables

(On hub order furnish bore dia. & keyway dimensions. On electrical parts specify voltage, phase & frequency.)

### REPLACEMENT BRAKE

Model Number

Voltage, Phase & Frequency

Hub Bore & Keyway Dimensions

Mounting - Horizontal or Vertical. (If vertical, specify whether above or below motor. If brake includes foot mounting bracket or adaptor, specify.)

 **Dings** DYNAMICS GROUP



4740 W. ELECTRIC AVE. • MILWAUKEE, WI 53219 • 414/672-7830 • FAX 414/672-5354 • [www.dingsco.com](http://www.dingsco.com)

Printed in U.S.A. BK4604 (12/01)