

G061070-001



2 Safety information

2.1 Persons responsible for the safety

Operator

- An operator is any natural or legal person who uses the spring-applied brake on behalf of whom the drive system is used.
- The operator or his safety officer are obliged
 - to check whether all relevant regulations, notes, and laws are observed,
 - that only qualified personnel work on and with the drive system,
 - to ensure that the personnel have the Operating Instructions available for all corresponding operations and
 - to prohibit non-qualified personnel from working with and on the controller.

Qualified personnel

Qualified personnel are persons who are - because of their education, experience, instructions, and knowledge about corresponding standards and regulations, rules for the prevention of accidents, and operating conditions - authorized by the person responsible for the safety of the plant to perform the required actions and who are able to recognize and avoid potential hazards. (see IEC 364, definition for qualified personnel).

2.2 General safety information

- These safety notes do not claim to be complete. In case of questions and problems please contact your Dings Co. representative.
- At the time of supply the spring-applied brake is state-of-the-art and ensures basically safe operation.
- The spring-applied brake is hazardous to persons, the spring-applied brake itself and other properties of the operator, if
 - that only qualified personnel work on and with the spring-applied brake.
 - that the spring applied brake is not used improperly.
- Spring-applied brakes must be designed so that they comply with their function and do not cause any hazards to persons when correctly installed and in fault-free operation as directed. This is also effective for the interaction with the entire system.
- The spring-applied brake must only be operated in perfect state.
- Retrofittings or changes of the spring-applied brake are generally prohibited. In any case, Dings Co. must be contacted.
- The friction linings must be carefully protected from grease or oil since even small amounts of lubricants reduce the brake torque considerably.
- With application conditions according to enclosure IP54, the brake torque will usually not be reduced. Because of the great variety of applications, it is however necessary to check the functionality of all mechanical components under the specific conditions.



Possible applications of the spring-applied brake:

- No explosive or aggressive atmosphere.
- Humidity, no restriction.
- Ambient temperature -20°C through +40°C.
- With high humidity and low temperatures
 - Take measures to protect armature plate and rotor from freezing.
- Electrical connections must be protected against contact.

2.3 Layout of the safety information

- All safety information given in these Operating Instructions has the same layout:



Signalword!

Note

- The icon characterizes the type of danger.
- The signal word characterizes the severity of danger.
- The note describes the danger and suggests how to avoid the danger.

Warning of danger for persons


Icons used		Signal words	
Warning of hazardous electrical voltage	Danger!	Warns of impending danger . Possible consequences if disregarded: Death or very severe injuries.	
	Warning!	Warns of potential, very hazardous situations . Possible consequences if disregarded: Death or very severe injuries.	
Warning of a general danger	Caution!	Warns of potential, hazardous situations . Possible consequences if disregarded: light or minor injuries.	

Warning of material damage

Icons used		Signal words	
	Stop!	Warns of potential damage to material . Possible consequences if disregarded: Damage of the drive system/controller or its environment.	

Other notes

Icons used		Signal words	
	Note!	Indicates a general, useful note. If you observe it, handling of the controller/drive system is made easier.	



Technical data

3 Technical data

3.1 Product description




Fig. 1 Spring-applied brake: D57 Compact, completely mounted with rotor and flange





Fig. 2 Spring-applied brake: D57 Basic, Stator complete with rotor



3.1.1 General

The spring-applied brake D57-□□ is a single disc pulley with two friction surfaces. The brake torque is generated by several (size 72...170) pressure springs. The brake is released electromagnetically.

The spring-applied brake D57-□□ is designed for the conversion of mechanical work and kinetic energy into heat energy. For operating speeds see chapter 3.2, Rated data. Due to the static brake torque, the brake can hold loads without speed difference. Emergency braking is possible at high speed, see chapter 3.2, Rated Data. The more friction work, the higher the wear. Please take into account that the friction value and thus the torque depend on the speed.



Stop!

The spring-applied brakes D57, sizes 72 to 170 use spacers. It is not possible to readjust the brake in the event of wear. If necessary, the rotor must be replaced.

3.1.2 Braking

When braking, the rotor (2.0), which is moveable on the hub (3.0), is pressed against the friction surface by the inner and outer springs (1.4) via the armature plate (1.2). The asbestos-free friction linings ensure a high brake torque with low wear. The brake torque is transmitted between hub (3.0) and rotor (2.0) via the splines.

3.1.3 Brake release

In braked state, there is an air gap $s_{Lü}$ between stator (1.1) and armature plate (1.2). To release the brake, the stator coil (1.1) is excited with the DC voltage provided. The resulting magnetic force attracts the armature plate (1.2) towards the stator (1.1) against the spring load. The rotor (2.0) is released from the spring load and can rotate freely.




Technical data

3.2 Rated Data

Model	Brake torque rated value at $\Delta n=100\text{min}^{-1}$ $M_k^{1)}$ [Nm]	Air gap $S_{LU} \pm 0.1$ [mm]		Tightening torque of the fixing screws [Nm]	Moment of inertia of the rotor [kg cm ²]	Brake mass [kg]		Outer Diameter [mm]	Pitch circle					
		rated ²⁾	max.			Compact	Basic		\varnothing [mm]	weight				
D57-072	4	0.2	0.6	2.8	0.130	1.1	0.9	84	72	3 x M4				
	6		0.4											
D57-090	8		0.6	5.5	0.450	1.9	1.5	102	90	3 x M5				
	12		0.45											
D57-112	16		0.3	0.7	9.5	2.000	3.8	3.0	130	112	3 x M6			
	23			0.5										
D57-132	32			0.8								4.500	5.7	4.7
	46			0.5										
D57-145	60			23.0		0.8	6.300	8.6	7.1	165		145	3 x M8	
	90					0.5								
D57-170	80	0.9	15.000		12.0	10.0					190			170
	125	0.6												

Model	Electrical power P_{20} [W]	Voltage U [V]	Coil resistance R_{20} [Ω]			Maximum speed Δn_{omax} [min ⁻¹]
			Rated	Max.	Min.	
D57-072	20	24	28.8	30.24	27.36	12400
		205	2101	2269	1933	
D57-090	28 25	24	20.57	21.6	19.54	10100
		205	1681	1807	1955	
D57-112	30 33	24	19.2	20.16	18.24	8300
		205	1273	1356	1191	
D57-132	40	24	14.4	14.83	13.97	6700
		205	1051	1082	1019	
D57-145	50	24	11.52	11.87	11.17	6000
	53	42	33.28	34.28	33.28	
	55	205	764	787	741	
D57-170	55	24	10.47	10.78	10.16	5300
		42	32.07	33.03	31.11	
		205	765	787	742	





4 Installation







Warning!

Toothed hub or screws must not be lubricated with grease or oil!

4.1 Required tools

Model	Torque wrench Measuring range [Nm]	Insert for hexagon socket screws Opening [Inch]
		
D57-090	0.5 - 13	3x1/4" square 55mm long
D57-112		4x1/4" square 55mm long
D57-132	3 - 40	5x1/2" square 180mm long
D57-145	20 - 100	6x1/2" square 140mm long
D57-170		

Feeler gauge	Caliper gauge	Multimeter
		



Installation

4.2 Assembly

4.2.1 Preparation

1. Unpack spring-applied brake.
2. Check for completeness
3. Check nameplate data, especially rated voltage.

4.3 Installation

4.3.1 Installation of the hub onto the shaft






Fig. 5 Installation of the hub onto the shaft

1. Press hub (3.0) onto the shaft.
2. Secure hub against axial displacement (e.g. using a circlip - 3.1).





4.3.2 Installation of the brake D57, compact design

1. Hub (3.0) installation, chapter 4.3.1.
2. Push spring-applied brake (1.0) onto the hub (3.0). Secure hub against axial displacement (e.g. using a circlip - 3.1).
3. Bolt the spring-applied brake (1.0) to the endshield using the fixing screws (8.1).



4. Tighten the screws (8.1) evenly (for torques see the table Rated data, chapter 3.2).







Installation



4.3.3 Installation of the brake D57, basic design

1. Mount the hub (3.0), chapter 4.3.1
2. Push the spring-applied brake onto the hub (3.0), secure the hub against axial displacement with a circlip (3.1).



3. Tighten the brake fixing screws lightly and remove the shipping brace (elastic band).
4. Tighten the screws (8.1) evenly (for torques see the table Rated data, chapter 3.2).
5. Remove the cheese head screws.





4.4 Electrical connection



Warning!

The brake must only be electrically connected when no voltage is applied.





Fig. 6 Switching parallel to motor, extremely delayed engagement



Installation




Fig. 7 DC switching, delayed engagement




Fig. 8 DC switching, normal engagement





Fig. 9 Separated DC voltage, DC switching.



5 Commissioning and operation



Warning!

Live connections must not be touched.
The motor must not be connected when checking the brake.

5.1 Operational test

In the events of faults see chapter 7 Troubleshooting and elimination.

5.1.1 Release / voltage check



Warning!

The brake must be free of torque. The motor must not rotate.




Warning!

Live connections must not be touched.

1. Remove two bridges from the motor terminals. Do not switch of the DC brake supply. When connecting the rectifier to the star point of the motor, the PEN conductor must also be connected at this point.
2. Switch on the current.
3. Measure the DC voltage at the brake.
4. Compare the DC voltage with the voltage indicated on the nameplate. A 10% deviation is permissible.
5. The air gap must be zero and the rotor must rotate freely.
6. Switch off the current.
7. Bolt bridges to the motor terminals. Remove additional PEN conductor.

5.2 During operation

- Check the brake regularly during operation. Take special care of:
 - unusual noises and temperatures
 - loose fixing elements
 - the state of the cables.
- In the event of failures, refer to the trouble shooting table in chapter 7. If the fault cannot be eliminated, please contact the Dings representative.



Maintenance

6 Maintenance / repair

6.1 Inspection intervals

The wear of the friction lining of the rotor depends of the operating conditions. The running time of the brake depends on the friction work per switching operation and on the differential speed. The inspection intervals must be adapted to the operating conditions and can be prolonged if the brake shows minimum wear.

6.2 Inspections

6.2.1 Inspection of brake D57

6.2.1.1 Air gap



Warning!

The motor must be at standstill when checking the air gap.

1. Measure the air gap " $s_{L\ddot{u}}$ " between armature plate and stator using a feeler gauge.
2. Compare the measured air gap with the maximum permissible air gap " $s_{L\ddot{u}max}$ ". (See table Rated Data, chapter 3.2).
3. If necessary, replace the rotor.

6.2.1.2 Releasing / voltage



Warning!


The running rotor must not be touched.



Warning!

Live connections must not be touched.

1. Observe air gap " $s_{L\ddot{u}}$ " during operation of the drive. It must be zero.
2. Measure DC voltage at the brake during operation. The voltage must be the same as indicated on the nameplate. A 10% deviation is permissible.



6.3 Maintenance

6.3.1 Maintenance of brake D57



Warning!

Switch off the voltage. The brake must be free of residual torque.

1. Loosen connection cable.
2. Unbolt fixing screws and remove brake from endshield. Observe connection cable.
3. Pull rotor from hub.
4. Check hub splining. In the event of wear, replace hub.
5. Check rake function according to the description of the inspection given in chapter 6.2.1.
6. If necessary, install new brake.

6.4 Spare-parts list

Only parts with order numbers available.

The order numbers are only valid for standard versions.

- Bore diameter in mm
- Standard keyway to DIN 6885/1 P9




Fig. 10 Spare parts for spring-applied brakes

Pos.	Name	Variant				
		Size	Voltage	Brake torque	Basic	Compact
1.0	Spring-applied brake	Size	Voltage	Brake torque	Basic	Compact
2.0	Rotor	Size	----	----	----	----
3.0	Hub	Size	Bore	----	----	----



7 Troubleshooting and fault elimination

Fault	Cause	Remedy
Spring-applied brake does not release, air gap is not zero	Coil is interrupted	<ul style="list-style-type: none"> Measure the coil resistance using a multimeter: <ul style="list-style-type: none"> If the resistance is too high, replace the spring-applied brake.
	Coil has contact to ground or between the windings	<ul style="list-style-type: none"> Measure the coil resistance using a multimeter: <ul style="list-style-type: none"> Compare measured resistance to rated resistance. For values see chapter 3.2 Rated data. If the resistance is too low, replace the spring-applied brake. Check coil for contact to ground using a multimeter: <ul style="list-style-type: none"> In case of contact to ground, replace the spring-applied brake. Check brake voltage (see defective rectifier, voltage too low).
	Wiring wrong or defective	<ul style="list-style-type: none"> Check and correct wiring. Check cable for continuity using a multimeter: <ul style="list-style-type: none"> Replace defective cable.
	Rectifier defective or wrong	<ul style="list-style-type: none"> Measure DC voltage at the rectifier using a multimeter: <ul style="list-style-type: none"> If DC voltage is zero: <ul style="list-style-type: none"> Measure AC voltage at the rectifier. If AC voltage is zero: <ul style="list-style-type: none"> Apply voltage, check fuse, check wiring If AC voltage is o.k.: <ul style="list-style-type: none"> Check rectifier, replace defective rectifier If DC voltage is too low: <ul style="list-style-type: none"> Check rectifier, Use half-wave rectifier instead of bridge rectifier. If diode is defective, use suitable new rectifier Check coil for contact to ground or between the phases. If a rectifier defect occurs more than once, replace the spring-applied brake even if a contact to ground or between the windings cannot be measured. The fault may occur only in the warm state.
	Air gap too large	Replace the rotor.
Rotor thickness too small	Spring-applied brake was not replaced in time	Replace spring-applied brake (chapter 4.3.1 and 4.3.2).
Voltage too high	Brake voltage does not match with rectifier	Adapt rectifier and brake voltage to each other.
Voltage too low	Brake voltage does not match with rectifier	Adapt rectifier and brake voltage to each other.
	Defective rectifier diode	Replace rectifier by a suitable new one.
AC voltage is not mains voltage	Fuse missing or defective	Select connection where fuse has not been removed and is o.k.